

WorldWEIGH

Technical Manual

BWS
Platform Scales

CONTENTS

| | |
|--|----|
| 1. SPECIFICATION..... | 2 |
| 2. INTRODUCTION..... | 3 |
| 3. INSTALLATION..... | 4 |
| Precautions | 4 |
| Parts..... | 4 |
| Installation..... | 5 |
| 4. KEYS DESCRIPTION..... | 6 |
| Key Board..... | 6 |
| Secondary functions of the keys..... | 7 |
| Display..... | 7 |
| 5. OPERATION..... | 8 |
| 5.1. Basic Operation..... | 8 |
| 1. Power On /Off..... | 8 |
| 2. Zero..... | 8 |
| 3. Tare..... | 8 |
| 4. Select Unit..... | 8 |
| 5.2. Check Weighing..... | 9 |
| 5.2.1. Set Limits..... | 9 |
| 5.2.2. Set Check Weighing..... | 9 |
| 5.3. Accumulation..... | 10 |
| 5.3.1. Memory Recall..... | 10 |
| 5.3.2. Memory Clear..... | 10 |
| 5.3.3. Automatically Accumulation..... | 10 |
| 5.4. Parts Counting..... | 11 |
| 5.5. Animal Weighing..... | 11 |
| 5.6. Key Board Lock..... | 11 |
| 5.7. Set Auto Power Off..... | 12 |
| 5.8. Set Back Light..... | 13 |
| 6. PARAMETERS..... | 14 |
| 7. CALIBRATION..... | 16 |
| 8. RS-232 OUTPUT..... | 17 |
| 8.1. Specifications..... | 17 |
| 8.2. Connector..... | 17 |
| RS-232 Output..... | 17 |
| Check weighing Output..... | 17 |
| 8.3. Continues output protocol..... | 17 |
| 9. DRAWING..... | 19 |
| 9.1. Drawing..... | 21 |
| 9.2. Parts List..... | 22 |

PRECAUTIONS


| | |
|---|--|
|  |  WARNING |
| | DISCONNECT ALL POWER TO THIS UNIT BEFORE INSTALLING, CLEANING, OR SERVICING. FAILURE TO DO SO COULD RESULT IN BODILY HARM OR DAMAGE THE UNIT. |

| |
|--|
|  CAUTION |
| <ul style="list-style-type: none">• Permit only qualified persons to service the instrument• Before connecting or disconnecting any components, remove the power.• Failure to observe these precautions bodily harm or damage to or destruction of the equipment. |



- The platform scales is a precision electronic instrument, handle it carefully.
- Do not install the scale in direct sunlight.
- Verify the local voltage and receptacle type are correct for the scale.
- Only use original adaptor, other could cause damage to the scale.
- Pluggable equipment must be installed near an easily accessible socket outlet.
- Avoid unstable power sources. Do not use near large users of electricity such as welding equipment or large motors.
- Avoid sudden temperature changes, vibration, wind and water.
- Avoid heavy RF noise.
- Keep the indicator clean

1. SPECIFICATION



| Model | BWS | BWS-E |
|-------------------------|--|----------|
| Display | 52mm LCD | 1.2" LED |
| Housing | SST | |
| Operating Temperature | -10°C - 40°C / 14°F - 104°F | |
| Resolution | 1/6000 (OIML Approved) | |
| Key Pad | 7 Keys | |
| Power | AC Adaptor (12V/500mA)/ Battery (6V/4Ah) | |
| Calibration | Automatic External | |
| Interface | RS-232 Output Optional | |
| Load cell drive Voltage | Max: 5V/150mA | |
| Load Cells | Up to 4 load cell | |
| ADC | Sigma Delta | |
| ADC Update | ≤1/10 second | |
| Stabilization Time | One seconds typical | |

2. INTRODUCTION

- The BWS series platform scales that amplifies signals from a load cell, converts it to digital data and displays it as a mass value.
- It is suitable for general weighing or more specialized applications such as check weighing, animal weighing and accumulation applications.
- It can connect the indicator to a printer or a PC.
- Large LCD with white LED back light displays

3. INSTALLATION

Unpacking

When you receive the scale, inspect it to make sure that it is not damaged and that all the parts are included:

- Remove the Indicator from the carton.
- Remove the protective covering. Store the packaging and to use if you need to transport the scale later.
- Inspect the indicator for damage.
- Make sure all components are included.
 1. Indicator
 2. Adaptor
 3. Manual
 4. Indicator holder (Optional)
 5. Load cell Output connector (Optional)
 6. RS-232 Output Connector (Optional)

Parts Description



Installation


- Place the Indicator on a table or use indicator holder to connect with stand.
- Connect the platform load cell cable in to the indicator load cell connector. Load cell connector is located back side of the indicator.

- Connect the adaptor pin in to the indicator adaptor jack.
Adaptor jack is locating, back side of the indicator.
- Adaptor connects into your AC power socket.
Pluggable equipment must be installed near an easily accessible socket outlet with a protective ground/ earth contact.
- Turn on the On/Off key. If you want to turn off, press the key again.
- Display will be show the scale capacity and will be starting self checking.
- After self checking, display will be come to normal weighing mode.
- Warm-up time of 15 minutes stabilizes the measured values after switching on.
- Calibrate with exact calibration weights, minimum 1/3 of the scale capacity want to use for calibration. For calibration see details in parameter.

Then you can start your operation

4. KEYS DESCRIPTION

Key Board



| Keys | Description |
|---|---|
|  | Power turn ON/OFF |
|  | Set the Zero Display |
|  | To perform a tare function, Subtracts weights. |
|  | Accumulator key, current values will store to the memory, To send the data to printer or PC |
|  | Shift to Gross / Net Weight. |
|  | Counting |
|  | To change the unit |

Secondary functions of the keys

| Function | Keys |
|---|--|
| To confirm the selected menu |  A square key icon with a left-pointing arrow and the word "ZERO" below it. |
| To change the menu and active digit |  A square key icon with an upward-pointing arrow and the word "TARE" below it. |
| To move the active digit to right |  A square key icon with a right-pointing arrow, the text "ACC/TTL" above "Print", and the word "Print" below it. |
| To move the active digit to left |  A square key icon with a left-pointing arrow and the text "G/N" below it. |
| To enter in to the menu |  A square key icon with the text "SET" above "PCS" and the word "PCS" below it. |
| Escape from the menu to normal operation. |  A square key icon with the text "ESC" above "UNIT" and the word "UNIT" below it. |

5. OPERATION

Initial Start-up

Warm-up time of 15 minutes stabilizes the measured values after switching on.

5.1. Basic Operation

1. Power On/Off:

Switch on the balance by pressing on/ off key.

The display is switched on and the test is started and if want to switched off, press again the key.

2. Zero

Environmental conditions can lead to the balance exactly zero in spite of the platform not taking any strain. However, you can set the display of

your balance to zero any time by pressing  key and therefore ensure that the weighing starts at zero.

3. Tare

The weight of any container can be tared by pressing  button so that with subsequent weighing the net weight of the object being weighed is always displayed.

- Load weight on the platform.
- Press  key. Zero is displayed, and tare is subtracted.
- Remove weight on the platform. Tared weight is displayed. It can set only one tare value. It will be shown with a minus value.
- Press G/N to change between gross weight and net weight.
- To clear the tare value, remove the load and press  key. Zero is displayed, tare weight is cleared.

4. Select Unit and Sampling operation

Press  key, it can change unit and sampling operation.

5.2. Check Weighing

It can set an upper or lower limit when weighing with the limits range. During the limit controls dividing the unit will indicate whether a value upper or lower limits with an alarm sound .

5.2.1. Set Limits

- Press  and  key together, display will be show **set h**.
- Press  key to select **set h** or **set l**
- Press  key to confirm, display will show **00000** and will blink the last digit.
- Enter the high limit value by using  and  keys to change the active digits and press  key to increment the value.
- Press  key to confirm, display will show **set l**
- Enter the high limit value by using  and  keys to change the active digits and press  key to increment the value.
- Press  key to confirm.
- To escape from the settings press  key.

5.2.2. Set Check Weighing

- Press  and  key together, display will be show **set h**.
- Press  key to select display **beep**.
- Press  key to confirm, display will be shown **none** or **ok** or **ng**
- **Check mode none** : No beep sound in the limits. Function turned off.
- **Check mode ok** : When the weight is between the limits. OK will shown

and beeper will be sounded.

- **Check mode ng** : When the weight is out of the limits, the beeper will be sounded and OK will shown.

Note: Check weighing available only when weight more than 20d

5.3. Accumulation

The scale can be set to accumulate manually by pressing  key. For settings, see the parameter **p 1 Com » mode » pr 2**
Before operation scale should be stable and return to zero, accumulation available only when weight more than 20d

Accumulation Operation

- Place the load on the platform.
- Press  key, when displayed STABLE indication.
- Display will be show **acc 1** then will be show the total saved value. These displays will be shown only three seconds.
- Remove the weight from the pan.
- When display get zero and stable then place the second weight.
- It can continue until the memory gets fully or 99 items.

5.3.1 Memory Recall

To recall the memory press  key.

Display will be show **acc X** (X: Total number of accumulation) then will be show the total saved value. These displays will be shown only three seconds.

5.3.2. Memory Clear

To clear the memory, press  and  keys together.

Display will be show **Acc 0** , all accumulation memory cleared from the memory.

5.3.3. Automatically accumulation.

The scale can be set to accumulate automatically. For settings, see the parameter **p 1 Com » mode » auto**

Automatic Accumulation Operation

- Place the load on the platform.
- When display gets STABLE indication, display will be show **acc 1** then will be show the total saved value. These displays will be shown only three seconds.
- Remove the weight from the pan.
- When display get zero and stable then place the second weight.
- It can continue until the memory gets fully or 99 items.

5.4. Parts Counting

To enter the parts counting, press  key and select until display will be show **p 10**

Press  to change the parts quantity.
Options: **p10 / p 20 / p 50 / p100 / p 200**

Parts Counting Operation

- Select the parts quantity as per the option
- Place the load on the platform
- Press  key to confirm, display will be shown ---- then will show the quantity
- Then can add goods on the platform, display will update the parts quantity automatically

Press  key back to the weighing mode..

5.5. Animal Weighing

BWS can use for vibrate loads weigh. This function can use for animal weighing. For settings, see the parameter **p 3 oth » anm**

Bring the load on the platform, when the load few seconds get stable, the reading will be locked for few seconds.

It can add or remove loads also update the weighing locked values.

To enter or exit animal weighing mode, press  key until HOLD indicator will be displayed or not.
 When in animal weighing mode **HOLD** indicator will be displayed.

5.6. Keyboard Lock

It can set lock key board, for settings, see the parameter **p 3 oth » lock**

When the keys are not using with in 10 minutes, the keys will be lock automatically.
 After entering into the lock function, when we press the keys display will be show **k-loc**. Then will come to normal display.

If want to unlock and want to use the keys press and hold ,  and  keys three seconds. Display will be show **u lck** Then will come to normal display

5.7. Set auto power off

It can set auto power of the scale, when scale not in use, scale will turn off after the setting time.

- Hold  key three seconds display will show **setbl**
- Press  key to change **Set of** and press  key to confirm
- Press  key to change the options.

| | | |
|---------------|--------------|--|
| Set of | off | To set auto off function turn off, for scale always on |
| | Of 5 | Set to turn off five minutes later |
| | Of 15 | Set to turn off fifteen minutes later |

- After select the auto off option press  key to confirm and press  key to escape from the settings.

5.8. Set Back Light

It can set back light when scale in use.

- Hold  key three seconds display will show **setbl**
- Press  key to confirm

| | | |
|--------------|------------|---|
| setbl | au | To set auto option. When start to use back light will be on and when stop the operation back light also will off. |
| | on | To set always on. After turn on the power, back light also will be on. |
| | off | To set back light turn off. No back light in the operations |

- After select the back light option press  key to confirm and press  key to escape from the settings.

6. PARAMETERS

To set parameter, turn on the scale.

- Press  key during the self checking.
- Display will be show **pn**
- Press ,  and  to enter, display will be show **po chk**

| Menu | Sub Menu | Description | |
|---------|----------|---|--|
| P 0 chk | Set H | Set high limits for check weighing | |
| | Set lo | Set low limits for check weighing | |
| | beep | No | No beep for check weighing |
| | | Ok | Beep, when check weighing between the limits |
| ng | | Beep, when check weighing out of the limits | |
| P 1 com | Mode | <p>This option is used to set accumulation and RS-232 communication</p> <p>Options:</p> <p>Cont : data send continues</p> <p>St 1 : Send data one time, when stable.</p> <p>St c : Send data continuously, when stable</p> <p>P r1 : Send data one time, when press print Key (in printer mode)</p> <p>Pr 2 : Send data to print and accumulation, When press .key</p> <p>Auto : Auto accumulate and auto print mode. When weight stable and return to zero.</p> <p>Ask : Ask mode, Command R: read data Command T: Tare Command Z: Zero</p> <p>Wireles: Wireless mode (communication through wireless)</p> <p>KIT 1 :</p> | |
| | Baud | To set the baud rate. Options: | |

| | | | | | |
|----------------|---------------|--|--|----------------------------------|--|
| | | 600 / 1200 / 2400 / 4800 / 9600 | | | |
| | Pr | To set the parity Options: 7 e1 / 7 o1 / 8 n1 | | | |
| | Ptype | To set printer model Options: TM220 : set the Tscale printer tm220 Lp50 : Set the Tscale printer LP-50 TM295 : set the Tscale printer tm295 | | | |
| | LAB | | | | |
| P 2 mod | Si g r | To select single range operation | | | |
| | | Count | To check internal counts | | |
| | | Deci | To set decimal points | | |
| | | Div | To set increment | | |
| | | Cap | Set Capacity | | |
| | | Cal | Calibration | | |
| | | gra | Gravity | | |
| | Dual 1 | To select dual range - mode 1 Note: Once active second interval (div 2), Then second interval will work until display return to zero | | | |
| | | Count | To check internal counts | | |
| | | Deci | To set decimal points | | |
| | | Div | Di v 1 | To select first division | |
| | | | Di v 2 | To select second division | |
| | | Cap | Cap 1 | To select first capacity | |
| | | | Cap 2 | To select second capacity | |
| | | Cal | Calibration | | |
| | | gra | Gravity | | |
| | | Dual 2 | To select dual interval - mode 2 Note: First interval will active in CAP 1 Second interval will active in CAP 2 | | |
| | Count | | To check internal counts | | |
| | Deci | | To set decimal points | | |
| | Div | | Di v 1 | To select first division | |
| | | | Di v 2 | To select second division | |
| | Cap | | Cap 1 | To select first capacity | |
| | | | Cap 2 | To select second capacity | |
| | Cal | | Calibration | | |
| | gra | Gravity | | | |
| | P3 oth | Lock | To set keypad lock | | |

| | | |
|---------------|---------------|---|
| | | Options: on / off |
| | anm | To set animal mode. Options: on / off |
| P4 S T | ST ON | |
| | ST OFF | |
| P5 CLR | CLRCAL | Clear the calibration record |
| | CLROPT | Clear the parameter modification record |

7. CALIBRATION

To set calibration, turn on the scale.

- Press  key during the self checking.
- Display will be show **pn**
- Press ,  and  to enter, display will be show **po chk**
- Press  until display will be show **p 2 mod.**(These is a switch on the main board you need to press it then can into the parameter)
- Press  key to confirm and press  to select **sigr /dual 1 /dual 2**
- Press  key to confirm and press  to select **cal**
- Press  key to confirm

Calibration Cal

- Press  key to enter calibration, display will be show **unld**
- Remove all the weight from the platform.
- When indicator get stable, press  key to confirm.
- Display will be show the last calibration weight. If want to change the calibration weight value, press  and  keys to change the active digits and press  key to increment the value.
- When the calibration value is correct, press  key to confirm.

- Display will be show **load**
- Place the calibration weight on the platform.
- When indicator get stable, press  key to confirm.
- Display will com to normal weighing mode

8. RS-232 OUTPUT

8.1. Specifications:

RS-232 output of weighing data

Code : ASCII
 Data bits : 8 data bits
 Parity :No Parity
 Baud rate : 600bps to 9600bps selectable

8.2. RS-232 (9pin D type connector)

| | | | |
|-------|-----|--------|-------------------|
| Pin 2 | RXD | Input | Receiving data |
| Pin 3 | TXD | Output | Transmission data |
| Pin 5 | GND | — | Signal ground |

9pin D Connector:

Indicator

Pin 2:
 Pin 3:
 Pin 5:

Computer

Pin 3
 Pin 2
 Pin 5

Check Weighing Output

Pin 1 : VB
 Pin 4: Vcc 5v (Output)
 Pin 5: Com (Ground)
 Pin 6: Ok (Output)
 Pin 7: Low (Output)
 Pin 8: Hi (Output)
 Pin 9: Beep (Output)

8. 3. Continuously output protocol

Weighing mode

| | | | | | | | | | | | | | | | | | | | | | |
|-----------|--|----------|--|-------------------|--|--|--|--|--|--|--|--|--|--|--|---------------|--|------------|---|----|----|
| | | , | | -/□ | | | | | | | | | | | | | | k | g | CR | LF |
| HEADER1-- | | HEADER2- | | -- WEIGHT DATA -- | | | | | | | | | | | | -WEIGHT UNIT- | | TERMINATOR | | | |

Counting mode

| | | | | | | | | | | | | | | | | | |
|---|---|---|---|--|--|--|--|--|--|--|-------|---|------------|---|---|----|----|
| P | C | S | : | | | | | | | | | □ | p | c | s | CR | LF |
| | | | | | | | | | | | -QTY- | | -QTY UNIT- | | | | |

HEADER1: ST=STABLE, US=UNSTABLE

HEADER2: NT=NET, GS=GROSS

Con2:

| | | | | | | | | | | | | | | | | | |
|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|-------|-------|-------|-------|-------|-------|-------------|-------------|
| Header0 | Header1 | Header2 | Header3 | Weight1 | Weight2 | Weight3 | Weight4 | Weight5 | Weight6 | Tare1 | Tare2 | Tare3 | Tare4 | Tare5 | Tare6 | Terminator1 | Terminator2 |
|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|-------|-------|-------|-------|-------|-------|-------------|-------------|

Header0=02H

Header1 follow decimal point

Decimal point=0, header1=22H

Decimal point=1, header1=23H

Decimal point=2, header1=24H

Decimal point=3, header1=25H

Decimal point=4, header1=26H

Header2 follow weigh status, default value=20H

If in net mode (tare value not 0), header2=header2|01H

If gross weight “-“, header2=header2|02H

If overload or gross weight “-“, header2=header2|04H

If unstable, header2=header2|08H

If weighing unit=kg, header2=header2|10H

Header3 follow weighing unit

If weighing unit=g, header3=21H

If weighing unit=oz, header3=23H

Weight1~weight6: weighing data

Tare1~tare6: tare value

Terminator1: 0DH

Terminator2: 0AH

Con3:

| | | | | | | | | | | | | | |
|---------|---------|---------|---------|---------|---------|---------|---------|---------|-------|-------|--------|-------------|-------------|
| Header0 | Header1 | Weight1 | Weight2 | Weight3 | Weight4 | Weight5 | Weight6 | Weight7 | Unit1 | Unit2 | Status | Terminator1 | Terminator2 |
|---------|---------|---------|---------|---------|---------|---------|---------|---------|-------|-------|--------|-------------|-------------|

Header0=01H

Header1 follow weight “+” or “-“

When weight “+“, header1=“+“, when weight “-“, header1=“-“

Weight1~weight7: weight data (include decimal point)


Unit1~unit2: weight unit

Status: when stable, status=0, when unstable, status=1

Terminator1: 0DH
Terminator2: 0AH

9. DRAWING

9.1. Drawing



9.2. Parts List

| No | Parts | Qty | Spec |
|----|-----------|-----|------|
| 1 | Key Panel | 1 | |

| | | | |
|----|-------------------------------|---|-----------|
| 2 | Front Cover | 1 | |
| 3 | Display Protection Plate | 1 | |
| 4 | Nut | 6 | M3*6 |
| 5 | Main PCBA | 1 | |
| 6 | Washer | 6 | 8x3.1x1.5 |
| 7 | Star (+) Self Thread screw | 6 | M3x8 |
| 8 | Water Proof Rubber Bar | 1 | |
| 9 | Star (+) Screw | 2 | M4x10 |
| 10 | Washer | 2 | M4 |
| 11 | Battery Clamp | 1 | |
| 12 | Washer | 6 | M4 |
| 13 | Star (+) Big head Screw | 6 | M4x12 |
| 14 | Bracket | 1 | |
| 15 | Bracket Screw | 2 | |
| 16 | Water Proof Adaptor jack | 1 | |
| 17 | Interface Module | 1 | |
| 18 | Air connecter | 1 | 5Pin |
| 19 | Plug | 1 | |
| 20 | Rubber Spacer | 3 | |
| 21 | Air Connector | 1 | 7Pin |
| 22 | Back Cover | 1 | |
| 23 | Air Connector Water Proof Nut | 1 | |
| 24 | Battery | 1 | 6V/4Ah |
| 25 | Nut | 1 | M3x6 |
| 26 | Main Serial board | 1 | |
| 27 | Spacer | 1 | |
| 28 | Star (+) Screw | 1 | 3Mx20 |
| 29 | Micro Switch Cap | 7 | |