

## C100 Remote Serial Print and Function Commands

Add <013><010> after each command listed below. All work except for the P<013><010>, Use M+ instead.

### Basic Commands:

PLUxx	Select PLU from scale memory
T	Tare current weight value
T123.456	Numeric tare value
Z	Zero
P	Print
M+	Store and print current results
MR	Recall memory values to scale display
MC	Clear memory
U123.456	Store unit weight of 123.456 kg / lb
S123	Enter sample size of parts 123 . Same as pressing
SL	Select local scale to be used
SR	Select remote scale to be used

### Printing Commands:

\L	Scale: Local or Remote
\I	User ID number
\S	Scale ID number
\N	Net weight
\G	Gross Weight
\T	Tare weight
\U	Unit weight
\P	Count
\C	Total Count
\W	Total Weight
\M	Number of items stored in memory
\B	A blank / space line

GSE Rabbit(tm) - [Terminal Screen 1]

File Comm Terminal Edit Tools Language Window Help

Editor

Receive Data

```

LOCAL SCALE
ID
SCALE
1.3654 lb NET
1.3654 lb GROSS
0.0000 lb TARE
0.0000 lb U.W.
20 PLS
20 TPC
1.3654 lb TWI
1 MO
  
```

Send Data

Setup Pages

- Mac Tare
- Mac Numeric Tare
- Mac Zero
- Mac Print
- Mac CLR
- Mac UO.33
- Mac Sample
- Mac SL
- Mac SR
- Mac L
- Mac I
- Mac S
- Mac ON
- Mac O
- Mac IT
- Mac LT
- Mac IP
- Mac C
- Mac M+
- Mac W
- Mac M-
- Mac B

Button Area

Add Edit Execute

Remove Insert

Move Up Move Down

Mac-G13-G10

Open Save As

Opened: COM1:9600,8,0,N,None,0 Scale Port is ???