WorldWEIGH C100 Linear Calibration

If Calibration of your C100 seems to be off even after a Calibration. It may be necessary to perform a linear Calibration.

- Turn on the scale and press Zero during the self-test.

Pi n

- Use the numeric key to enter password

  Default password **9999**
  Press Tare to confirm

Pi n	- - - -

- Display will be shown
  Press Tare to confirm.

tech	Local

- Display will be shown
  If necessary, press U.WL Units to select the weighing unit **kg** or **lb.**
  Press Tare to confirm.

tech	unit

- Display will be shown
  Ensure the platform is empty
  and wait for stable indicator.
  Press Tare to confirm.

unload

- Display will be shown
  Load the Value indicated
  Press Tare to confirm.

A xxlb

- Display will be shown
  Load the Value indicated (full capacity)
  Press Tare to confirm.

A xxlb

- After the calibration scale will start a self-test, remove the weight during that time and display will return to weighing mode.

- Incase display will show any error message or incorrect measurement, repeat the calibration again.